

# 125-457871 - FOOT THROTTLE ASSEMBLY

Assemble the cable assembly as shown and then mount the rocker mount to the standoff and mount the rocker to the rocker mount. Clamp the the assembly to the stringer and place it to where it feels comfortable and mount the foot pedal to the rocker, to where it feels comfortable. Attach the rod end to the rocker and clamp the cable stop to the standoff. At this point you want to feel where idle position and full throttle position are at you might have to sacrifice some idle position to make full throttle not go over center. Now mount the cable stop to the standoff at about the same height as the reference punch mark . Finally mount the standoff to the stringer.

