



# MERC 600/662/700 IC FITTING KIT -10 AN

625-4614

The stock hose is pushed on the factory IC fitting barb and hose clamped. Remove hose clamp, pull hose off and push on push lock fitting. No cutting needed.

To install fittings, remove 2 bolts, pull out the 2 fittings. There just lightly pushed in and come right out.

Put orings on fittings, grease orings, install fittings. Lock in place with retaining plate, install factory bolts back in.

