


INSTALLATION INSTRUCTIONS: 1) INSTALL WEAR PLATE (C)INTO BODY(A). WEAR PLATE CAN ONLY FIT IN ONE DIRECTION. MAKE SURE THE SLOT FITS OVER THE ADJOINING KNOB IN BODY. 2) APPLY GREASE INSIDE BORE AREA. INSERT IMPELLER (D) INTO BORE. MAKE SURE IMPELLER BLADES ARE BENT IN THE DIRECTION SEA PUMP WILL BE SPINNING. THE BACK SIDE OF BODY SHOWS STANDARD LEFT HAND ROTATION.

3) INSTALL LARGER O-RING (B) IN THE O-RING GROOVE IN THE BODY. APPLY A LIGHT COAT OF GREASE TO O-RING. THIS WILL HOLD O-RING IN PLACE.

4) INSTALLER SMALL O-RING (F) INTO THE GROOVE IN YOUR STOCK MERCURY BEARING HOUSING. APPLY LIGHT COAT OF GREASE TO O-RING. THIS WILL HOLD O-RING IN PLACE. 5) SLIDE WEAR PLATE (E) OVER YOUR STOCK MERCURY SHAFT AND AGAINST THE BEARING HOUSING.

6) INSERT MERCURY SHAFT AND BEARING HOUSING ONTO SEA PUMP BODY ASSEMBLY. 7) APPLY ANTI-SEIZE TO THE THREADS OF THE SUPPLIED BOLTS. MAKE SURE TO USE THE LONG BOLTS IN THE SAME SPOT AS THE ORIGINAL BOLTS. THE LONG BOLTS ARE NEEDED TO ATTACH YOU SEA PUMP BRACKET.

	OPTIONAL STAINLESS STEEL FITTINGS: 540-222151 1" NPT x 1-1/4 HOSE BARB STRAIGHT. 540-222161 1" NPT x 1-1/4 HOSE BARB 45°. 540-222173 1" NPT x 1-1/4 HOSE BARB 90°.	HARDIN MARINE 11 Industry Dr. Palm Coast, FL 32137 386-445-2500 / FAX 386-445-1122			
THIS DRAWING IS CONFIDENTIAL AND IS SUPPLIED ON EXPRESS CONDITION THAT IT SHALL NOT BE LENT, COPIED OR DISCLOSED TO ANY OTHER PERSON OR USED FOR ANY OTHER PURPOSE WITHOUT WRITTEN CONSENT OF HARDIN MARINE INC BREACH OF THIS CONTRACT WILL HOLD AND IT'S PRINCIPALS LIABLE FOR LOSS AND DAMAGES.		TITLE:	MERCURY SE	EA PUMP REBL KIT	JILD
		A	DWG. NO. 625-41791 ALE: 1:1 DRAWN BY	PART NO. 625-4179 : J.P.STULL DATE: 0	REV



THIS DRAWING IS CONFIDENTIAL AND IS SUPPLIED ON EXPRESS CONDITION THAT IT SHALL NOT BE LENT, COPIED OR DISCLOSED TO ANY OTHER PERSON OR USED FOR ANY OTHER PURPOSE WITHOUT WRITTEN CONSENT OF HARDIN MARINE INC.. BREACH OF THIS CONTRACT WILL HOLD AND IT'S PRINCIPALS LIABLE FOR LOSS AND DAMAGES.