




**UNIVERSAL CHEVROLET
 ENGINE WIRING HARNESS**
 P/N 620-08802
 P/N 620-08804



- | | |
|---------------------------------------|--------------------------------|
| 1 - 12 VOLT ON STARTER | 10 - CIRCUIT BREAKER |
| 2 - "S" ON STARTER | 11 - POSITIVE TERMINAL ON COIL |
| 3 - 12V ON STARTER | 12 - CIRCUIT BREAKER |
| 4 - "R" ON STARTER | 13 - OIL PRESSURE SENDER |
| 5 - STARTER SOLENOID | 14 - GROUND TO ENGINE BLOCK |
| 6 - STARTER SOLENOID | 15 - ALTERNATOR "EXC" TERMINAL |
| 7 - STARTER SOLENOID TRIGGER TERMINAL | 16 - ALTERNATOR CHARGE POST |
| 8 - NEGATIVE SIDE OF COIL | 17 - WATER TEMPERATURE SENDER |
| 9 - POINT TERMINAL ON DISTRIBUTOR | |